

GLAS*Source*

Highlight / Prestige Series Shower Enclosure

INSTALLATION INSTRUCTIONS

Model Numbers

SS11180
PSS11180


Door and Panel

When ordering repair parts, please give the following information:

1. Model Number
2. Part Number
3. Part Description
4. Color

To install your shower enclosure,
you will need the following:

- Level
- #31 Drill Bit
- Glazing Block
- Hack Saw
- 3/16" Carbide Drill Bit (for the tile walls)
- Phillips Screwdriver
- Silicone



Door Here

MD1000/
PD1000

Description	Qty	Part No.	Picture
1. Wall Channels	2	D-1006	
2. Wall Anchors	6	V-935	
3. 8 x 1 1/4" Screws	6	ZS8X114	
4. 6 x 3/8 Screws	4	ZS6X38	
5. Headers	1	SS-1101	
6. Curbs	1	SS-1101	
7. Glass Support Blocks	1	V-902	
8. In-Line Glass Panel	1		
9. Vertical Seal Vinyl	4	V-909	
10. Horizontal Seal Vinyl	4	V-906	
11. In-Line Post	1	SS-1103	
12. Header and Curb Fillers	2	SS-1102	
Options:			
5. Prestige Header	1	PS-1701	
6. Prestige Curb	1	PS-1701	


NOTE: Wall channels (1), wall anchors (2) and screws (3) that are used in stall shower installation, are shipped with the shower door. Read both door and stall instructions before starting installation.

1. Cut curb (6) to desired length. Place parallel with front of threshold and mark location with a pencil.
2. Place wall channel (1) into curb on stationary panel side and mark through holes provided in wall channel.
3. Place other wall channel (1) into curb on door side and mark through bottom hole only, then remove wall channel.
4. Drill marked holes using a 3/16" bit, then plug with plastic wall anchors (2).
5. Run a 1/4" bead of silicone on underside of curb and fill both ends of curb with silicone. Also silicone where ends of curb will sit on the threshold.
6. Set curb back in place with weep holes to inside of unit. Place wall channels (1) back into curb and secure using 8 X 1 1/4" (3)
7. Place glass support block(s) in curb on fixed panel side. Place fixed panel in curb, moving it all the way into the wall channel. Tack in place at the top of the panel with vertical seal vinyl (9).
8. Cut header (5) to size and place in position.
9. Find minimum measurement for curb filler on chart, and place the inline post that distance away from door side wall channel. Check the plumb of the wall on the door side and note how much the wall is out. If the wall leans to the center, then add this length to the curb filler, or if it is leaning away from center, add it to the header filler. Never exceed the minimum or maximum measurements for the curb filler for the door size, as noted in chart. Move the inline post so the measurements for the header and curb fillers are now corrected for wall conditions. This should leave the inline post in a plum condition.
10. Now check that the daylight opening between the inline post and the fixed panel wall channel is no larger than panel size-(1/2") and smaller than panel size -(1 1/2"). If daylight opening does not fall within these tolerances, then adjust inline post to correct. Remember that the min. and max. of the curb fillers (or daylight opening) must not be exceeded. Cut filler to size and snap in place with 1/8" lip to outside. Do not screw inline post until step 16.

(Refer to Shower Door Installation Instructions.)

11. Snip excess vinyl from latch jamb, and crimp in place at top and bottom. Holding inline post, slip latch jamb into place.
12. Install 3" vinyl channel, centered vertically on edge of glass and tap handle in place.
13. Set door (with hinge jamb attached) over door wall channel. The hinge clip on the door should be sitting on the curb filler. Pull door to latch jamb, aligning them by moving hinge side of door back and forth at top where you are holding it. This movement moves wall channel and header too. After aligning glass and latch jamb, hold wall channel and mark along inside edge of wall channel with a pencil.
14. Remove door and place wall channel back in position on line, and mark holes on wall. Drill holes, insert anchors, then secure wall channel with 8 X 1 1/4".
15. Reinsert door with hinge jamb over wall channel. Plumb and adjust as you had previously decided to do using length of header and curb filler for adjustment. Door in final position should have 3/16" margin from edge of glass to latch jamb. After locating this position, secure hinge jamb to wall channel by drilling #31 hole through holes provided and secure with 6 X 3/8".
16. Secure In-Line post (11) to curb (6) using the same system.
17. Parallel header with top of door by raising header on wall channel at either side and secure in-line post and wall channels to header on inside using 6 X 3/8".
18. Make final adjustments with latch jamb and secure to in-line post with 6 X 3/8" (4)
19. Finish installing the vertical seal vinyl (9) in wall channel and then in the in-line post. Also install horizontal seal vinyl (10) at bottom and top of stationary panel, both inside and out.
20. Adjust splash vinyl on bottom of door so that approximately 1/8" daylight space remains between bottom of splash vinyl and curb filler (12) with the door in the closed position.
21. Adjust handle or clip to meet magnet for fine adjustment if necessary.
22. Seal along inside and outside edge of metal and tile with silicone.

Header & Curb Fillers		
Min. Filler=Door Size Minus 1 7/8"		
Max. Filler=Door Size Minus 7/8"		
Model Number	Min.	Max.
D-1000-23	21 1/8"	22 1/8"
D-1000-24	22 1/8"	23 1/8"
D-1000-25	23 1/8"	24 1/8"
D-1000-26	24 1/8"	25 1/8"
D-1000-27	25 1/8"	26 1/8"
D-1000-28	26 1/8"	27 1/8"
D-1000-29	27 1/8"	28 1/8"
D-1000-30	28 1/8"	29 1/8"
D-1000-31	29 1/8"	30 1/8"
D-1000-32	30 1/8"	31 1/8"
D-1000-33	31 1/8"	32 1/8"
D-1000-34	32 1/8"	33 1/8"
D-1000-35	33 1/8"	34 1/8"
D-1000-36	34 1/8"	35 1/8"



GLAS*Source*

Highlight/Prestige Series Door and Panel Inline

Model SS11180/PSS11180 Door and Panel Inline
Special Height and Width

QTY.	Part# & Description	How to arrive at measurement
1	SS 1101/PS 1701 header	unit width both sides
1	SS 1101/PS 1701 curb (weep holes)	unit width both sides
2	SS 1102 filler	
1	SS 1103 180 degree post	unit height minus 1-1/4" *
2	D1006 wall channel	unit height minus 1-1/4" *
1	D1504 latch jamb	unit height minus 2 3/8" *
1	D1505 hinge jamb	unit height minus 2 3/8" *
1	D1503 hinge rail	unit height minus 3 1/4" *
1	V-522 hinge sleeve	unit height minus 3-1/4" *
1	D1502 bottom rail	door glass width minus 11/16" *
1	D1508 drip trough	door glass width minus 3/16" *
GLASS 1 piece	panel width	unit width minus door width, minus 1"
	panel height	unit height minus 1"

* These parts are from a MD/PD1000